

Spanware®

Standard IMP-Anchor Installation Guide:

Spanware® Standard IMP-Anchors are easily installed using Spanware® installation tool kit (Part Number IMP-ATC-375)

Step 1



Step 2



Step 3 & 4



To install Spanware® Standard anchors, use the following procedure:

1. Using the included 1-1/8" hole saw, drill through the outer metal lamination until the drill stop contacts the outer wall lamination.
2. Using the included torque-limited driver, drive the screw section into the IMP Panel until its castellated ferrule just "snaps past" the outer metal lamination of the IMP Panel.
3. Push the 3/8" x 2-1/4" stainless steel bolt through the stainless steel flat washer, then through the flange of the item to be attached to the wall, then through the wall spacer, then through the EPDM flat washer, then through the gasketed thrust washer, and lastly into the threaded screw section.
4. Using the included torque-limiting driver, tighten bolt to 4 ft*lbs. Do not overtighten the assembly. Overtightening the assembly will cause fastener/substrate failure and will compromise the assembly's ability to bear load and/or maintain a vapor and moisture tight seal.

This installation procedure should be used for the following anchors:

IMP-AD-375, IMP-AD-250, IMP-AD-210, IMP-AS-375, IMP-AS-250, IMP-AS-210, IMP-ASUV-375, IMP-ASUV-250, IMP-ASUV-210

Food Grade Solutions LLC Copyright 2022 ©

Food Grade Solutions LLC 559-834-1219 www.foodgradesolutions.com PO Box 69 Fowler, CA 93625
Spanware® and Food Grade Strut® are registered trademarks of Food Grade Solutions LLC, Fowler, Ca 93625 Patent Protected 7651056, 7926760, 7931242, 10746216, 10914334 and other patents pending.